

Z-Control Training Mode

With the Z-Control training mode, training on a ZIEGLER firefighting vehicle gets easier, cleaner and more flexible than ever before.

The simulation of a ZIEGLER proportioning system, as well as the optional simulation of the built-in centrifugal fire pump, allows users to practice operating the vehicle anytime, anywhere.


The extinguishing system remains completely dry and clean throughout the process. Neither water nor foam enters the system or the environment.

Depending on the mode, the vehicle's engine can remain turned off. This makes the training mode ideal for training sessions at the fire station, especially during inclement weather or in the winter months.

In active training mode, the operation of the proportioning system and, optionally, the centrifugal fire pump is realistically simulated: from turning on the pump to pressure control and foam proportioning to monitoring the system status – all directly at the vehicle's original pump control panel.

The simultaneous motorized control of any valves present further contributes to a better understanding of the system.

1 Activation
To activate it, press and hold the rotary knob on the pump control panel.




2 Selection
The first step is to select the components to be simulated.


In Training Mode+, only the foam system is simulated, the pump operates normally.




3 Options
In a pump simulation, the user can choose between tank suction and external suction.



4 System Check
The system checks whether all conditions for a successful simulation have been met.




5 Active Operation
Displays indicate the active mode with a blue frame. All other elements, such as buttons, messages and valves behave just as they would during a real operation.



6 Deactivation
In addition to being manually ended, the training mode ends automatically in the following situations:

- Turning off the ignition
- Releasing the parking brake
- Speed > 10 km/h



! Compatible with all municipal vehicles manufactured in 2021 or later.

The minimum requirements are Z-Control of the latest generation and a built-in centrifugal fire pump.

Illustrations may contain accessories and/or special equipment that are not part of the standard scope of delivery or service. Technical changes reserved. We cannot accept any liability for printing errors.

Ziegler

Albert Ziegler GmbH
Albert-Ziegler-Strasse 1
89537 Giengen/Brenz
Germany

Phone +49 (0)7322 951-0
Fax +49 (0)7322 951-211
info@ziegler.de



We provide security.
www.ziegler.de